

Manual Addendum - Writing Text Messages





1. Push On/Off Switch Up to the ON Position if device is not on

OR

If screen is not on and green light is flashing (unit in "low power" mode), Hold down the middle key to wake the unit up and start the screen

2. When FT2100 screen is on, press the "MSG" key to go to the message menu

3. Using the "Up" and "Down" arrow keys, highlight "Make Txt Msg" and push the middle yellow square "Enter" key to go in to the "Make Txt Msg" menu



Manual Addendum - Typing Free-form Text

Type  twice



Type  once



Type  twice



Type  once then



type  twice



Type  once



Type  once



Manual Addendum - Correcting Free-form Text

To remove a letter and type over it, backspace until the letter to be changed is highlighted in black. Use the space key to erase the letter, then backspace and type the new letter.

Text to correct



Type



twice



Type



twice



Type



twice to reach the

**end of the line, then continue
typing the rest of the message**

